

GDHE - Graphic Display for Hilare Experiments
version 3.7

Matthieu Herrb
CNRS-LAAS

February 2007

Contents

1	Overview	4
1.1	Starting GDHE	5
1.2	The GDHE Tcl package	5
1.3	Init file	5
1.4	Using the reader	5
2	The standard GDHE application	7
2.1	Description of a standard environment	7
2.1.1	The user interface	7
2.1.2	Describing the scene	8
2.2	Other Tcl procedures	9
2.2.1	object	9
2.2.2	redrawAllWindows	11
2.3	Pre-defined models	11
2.3.1	Mobile robots	12
3	Basic objects	14
3.1	box	14
3.2	cylinder	14
3.3	polygon	14
3.4	polyline	15
3.5	prism	15
3.6	sphere	15
3.7	ellipsoid	15
3.8	disk	16
3.9	picture	16
3.10	drawString	16
3.11	repere	16
4	The GDHE protocol	17
4.1	Requests	17
4.2	Client library	18
4.2.1	Initialization	18
4.2.2	Termination	18
4.2.3	Evaluating a Tcl expression	18
4.2.4	A simple example	18

4.3	Access control	19
5	The Tcl-OpenGL interface	20
5.1	Introduction	20
5.2	The display framework	20
5.3	OpenGL primitives	21
5.3.1	Handling of 3D display windows	21
5.3.2	Frames	23
5.3.3	Color	24
5.3.4	Other random procedures	24
5.3.5	Display lists	25
5.4	Tcl procedures and variables	26
5.4.1	Procedures called by Tcl	26
5.4.2	Variables used by GDHE	27
6	Extension modules	29
6.1	Numerical Terrain Models	29
6.1.1	readTerrain	29
6.1.2	readTerrainGeroms	29
6.1.3	terrain	29
6.1.4	deleteTerrain	30
6.1.5	infoTerrain	30
6.1.6	Terrains types	30
6.2	Planet	30
6.2.1	initPlanet	30
6.2.2	drawPlanet	31
6.2.3	planet	31
6.2.4	Bugs	31
6.3	Tkjpeg	31

Copyright (C) 1996-2007 LAAS/CNRS
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Chapter 1

Overview

This document presents the GDHE software for 3D visualization of robotics applications [1].

It is totally programmable by using of the Tcl/Tk [3, 4] scripting language. It uses the OpenGL [2] library to display the 3D primitives.

GDHE allows to build a 3D representation of the geometrical model of an environment and make it change with time. In order to achieve this, GDHE acts as a server that receives requests from a set of client processes. These requests describe the evolution of the model. Clients can be either modules that control a real system and that send data about the state of this system or simulation processes producing a simulated state of a virtual system.

GDHE accepts an unlimited number of clients, allowing to visualize simultaneously the state of multiple independent systems (for instance a multi-robots system).

Finally GDHE is able to record all the requests it receives from its clients to play them back later, without needing the clients.




Figure 1.1: A sample multi-robot simulation displayed in GDHE

1.1 Starting GDHE

```
gdhe [-l log-file]
```

The `-l` option specifies the pathname of the log file in which all display requests are stored. The `reader` application then reads this log file back and sends them back for play back to GDHE.

Warning! GDHE overwrites the log file at each startup. In order to play back a log file, care should be taken to not overwrite it by using a different log file, or no log file at all.

1.2 The GDHE Tcl package

GDHE is also available as a Tcl/Tk extension, that can be loaded in the `wish` (or `elwish`) interpreter, using the Tcl `load` command:

```
load exec_prefix/lib/gdhe.so
```

1.3 Init file

During startup GDHE reads the `.gdherc` file in the current directory, after loading the standard GDHE library (see chapter 2) and after creating the socket of the display server.

The `.gdherc` file can thus redefine some elements of the standard GDHE library.

To learn how to define an initial environment in the `.gdherc` file, please report to chapter 2.

If the `gdhe_after_setup_rc` variable is set in `.gdhrrc` it will be evaluated after the `setup` procedure has been called to define the standard environment.

1.4 Using the reader

The `reader` is a Unix application that can read log files created by GDHE (using the `-l` option) and play them back inside GDHE.

```
reader [-c] [-f file] [-h host]  
        [-n packets] [-d millis] [-p command] [-l]  
        [s factor]
```

-c compat mode: reads the old format log files.
-f *file* reads the specified *file*.
-h *host* connects to GDHE on specified *host*.
-n *packets* reads the log file *packets* commands at a time.
-d *millis* makes a pause of *millis* milliseconds between each
 command.
-p *command* stops each time the specified *command* is found in
 the log file.
-l lists the keywords recognized as *command* by the -p
 option.
-s *factor* speeds the play back by the integer *factor*.

Chapter 2

The standard GDHE application

GDHE includes a set of procedures developed at CNRS/LAAS for the visualization of experiments in the Robotics and Artificial Intelligence group.

2.1 Description of a standard environment

GDHE is highly programmable (see next chapters). However it is pre-configured with a set of functions that are well suited to represent the kind of environment in which the mobile robots of the LAAS. This default (or standard) configuration is described in this chapter.

2.1.1 The user interface




Figure 2.1: The default interface

The default GDHE user interface is made of 2 main windows: a window showing the scene

and a control window. The position of the observer can be modified by dragging with the left mouse button in the scene window.

The control panel offers the following settings:

Distance: the distance between the observer and the watched point in the scene.

elevation: the angle that the line of sight makes with the horizontal plane.

azimut: the direction of the line of sight measured around the vertical.

target X: x coordinate of the point watched by the observer.

target Y: y coordinate of the point watched by the observer.

target Z: z coordinate of the point watched by the observer.

Lights: controls the computation of the lighting of the scene.

Fill/Line: selects rendering with filled facets or lines.

Perspective/orthogonal: computes the rendering of the scene using a perspective, resp. orthogonal projection.

Dump EPS: generates a dump in Encapsulated PostScript format of the visualization window.

Quit: quits the GDHE application.

2.1.2 Describing the scene

In the standard GDHE application, the scenes are split in two parts: a fixed environment and mobile objects. These two parts are described in Tcl variables. In order to make changes to a scene, the values of these variables can be modified.

Mobile objects

To represent mobile objects, GDHE is using several parallel Tcl arrays, indexed by object names, which can be arbitrary strings:

- pos** a Tcl array containing the position of each object. if **pos** has 3 elements, they are $xy\theta$, the position in the $z = 0$ plane of the object. If **pos** has six elements, they represent the Bryant angles and the xyz position of the object in the 3D space.
- robots** a Tcl array containing for each object the Tcl code to draw the object. For readability purposes, this code usually consists of a single procedure invocation, including arguments. The name of this array suggests that mobile objects are robots, but it can be anything.
- platform** a Tcl array associating to each object some Tcl code to draw some instruments attached to the object. This array is particularly useful when drawing robots that can carry different type of instruments. **platform** does not need to be defined for each object.
- rs_trajectory** a Tcl array describing a Reed and Shepp style (a succession of arcs and straight line segments) in the local frame of the object, drawn in the horizontal plane of the scene.

The associative arrays of Tcl are used intensively here. An Object has a name, which is a string, and this name is used as an index in the various arrays described above to find out the various attributes of the object.

Example:

The **xr4000** procedure draws a Nomadic XR4000 mobile robot. To place such a robot in the environment at coordinates $x = 2m$, $y = 1m$ and $\theta = 0$, just choose a name for it (for instance **r1** and evaluate the following Tcl code:

```
set robots(r1) xr4000
set pos(r1) {2.0 1.0 0.0}
```

The, to make this robot move, one just have to modify the value of **pos(r1)**:

```
set pos(r1) {2.2 1.0 0.0}
```

This will redraw the XR4000 robot 20cm further down the Ox axis.

2.2 Other Tcl procedures

The standard GDHE application provides a certain number of pre-defined objects (the LAAS robots and some accessories), but also some primitives that help to build new objects or to handle display windows.

2.2.1 object

object *name* { *definition* }

This function automates the definition, compilation and display of OpenGL display lists. During the first call to **object** an OpenGL display list is created and associated with *name* while *definition* is interpreted and displayed.

Further calls to the same **object** procedure only draws the recorded OpenGL display list, discarding the *definition*.

Remarks:




Figure 2.2: A sample result

- the *definition* part of an object should not contain a variable part. All variables will keep the value they had when the argument is first evaluated, no matter how the Tcl quoting is done.
- there are some limits in the current implementation on the redefinitions of an existing object.

Example:

The following code defines the `desk` procedure that draws a table. This procedure uses object to create an OpenGL display list called **Desk**.

```
proc desk {} {

    object Desk {
        pushMatrix
        translate 0.6 0.4 0
        color 200 200 100
        # Upper plane
        box 0 0 0.8 1.20 0.8 0.02
        # sides
        box -0.6 0 0 0.02 0.8 0.8
        box 0.6 0 0 0.02 0.8 0.8
        # bottom
        box 0 0.4 0.4 1.20 0.02 0.4
        popMatrix
    }
}
```




Figure 2.3: A more complex example: an environment from the Marha project

This procedure can be later referenced in the `robots` array to place two desks in the environment:

```
set robots(desk1) desk
set pos(desk1) { 0 0 -90 }
set robots(desk2) desk
set pos(desk2) { 0 1.5 -90 }
```

2.2.2 redrawAllWindows

`redrawAllWindows`

Triggers an immediate redisplay of all OpenGL windows displayed. This command is only useful in a Tcl script to create an animation. When clients are sending requests to GDHE, redisplay is managed automatically when the global variable `auto_redisplay` is set to 1 (which is its default value).

2.3 Pre-defined models

This section describes the pre-defined objects in GDHE. These objects are all defined in the `Models` Tcl package. To add new objects to GDHE, the Tcl source file containing the definition of a Tcl procedure drawing this object at the origin should be placed in the `#{GDHE}/tcl` Tcl package.

2.3.1 Mobile robots

Hilare 2

The `h2` procedure displays the Hilare 2 robot from LAAS. The procedure `h2_platform { angle }` can be used as the value of the `platform` array to display the Hilare 2 laser scanner, oriented along *angle*.

Hilare 2bis

The `h2bis` procedure displays the Hilare 2bis robot from LAAS. The `arm { q1 q2 q3 q4 q5 q6 }` can be used as the value of the `platform` array to display the manipulator arm of Hilare 2bis, with articular coordinates $q_1 \dots q_6$.

Junior

The `junior` procedure displays the Junior robots from Midi-Robots. The `junior_platform { angle }` can be used as the value of the `platform` array to display the junior laser scanner, oriented along *angle*.

Lama

The `lama` procedure display the Lama robot made from VNII-Transmach. This procedure has 5 parameters corresponding to the 5 internal degrees of freedom of the robot: α_1 , α_2 , β_1 , β_2 et β_3 . The `lama_platine { azi site }` procedure can be used as the value of the `platform` array to display the platform holding the stereo rig of lama, oriented among *azi* and *site* angles.

XR4000

The `xr4000` procedure displays a XR4000 robot from Nomadic Technologies.

Scout

The `scout` procedure displays a Super-Scout robot from Nomadic Technologies.

B21r

The `B21r` procedure displays a B21r robots from iRobots. A version with all accessories added at LAAS is also available: `rackham`.




Figure 2.4: Know robots models

Chapter 3

Basic objects

To make it possible to create complex 3D models, GDHE provides a set of predefined primitive objects that can be used to build drawing procedures:

3.1 box

```
box  $x_0$   $y_0$   $z_0$   $dx$   $dy$   $dz$ 
```

Draws a parallelepiped parallel to the axes. The $(x_0 \ y_0 \ z_0)$ point is placed at the center of the lowest side.

3.2 cylinder

```
cylinder  $x_0$   $y_0$   $z_0$  axis  $d_1$  [ $d_2$ ] length [facets]
```

Draws a cylinder or a cone parallel to the axes. $(x_0 \ y_0 \ z_0)$ gives the center of the first facet. *axis* is **x**, **y** or **z** to indicate which is the main axis. d_1 and d_2 are the diameters at the two extremities. d_2 can be omitted, in which case a cylinder of diameter d_1 is produced. Finally *longueur* is the length of the cylinder.

If d_1 or d_2 has a negative value, the facet at the corresponding end of the cylinder is not drawn (and the corresponding diameter is $\|d_i\|$).

facets defines the number of facets used to approximate the cylinder. The default value is 12.

3.3 polygon

```
polygon  $n$   $x_0$   $y_0$  ...
```

Draws a polygon in the $z = 0$ plane. The coordinates of the n vertices are defined by $(x_0 \ y_0 \ x_1 \ y_1 \dots x_{n-1} \ y_{n-1})$

The normal of this polygon is oriented towards positive z .

If it has been declared beforehand (see **concave**), the polygon can be concave, but its edges should not cross themselves and there can be no double vertex (ie 2 vertices at exactly the same coordinates). Should this happen, the result is undefined.

3.4 polyline

```
polyline n x0 y0 z0 ...
```

Draws a sequence of 3D line segments. The coordinates of the n vertices are given by $(x_0\ y_0\ z_0\ x_1\ y_1\ z_1\ \dots\ x_{n-1}\ y_{n-1}\ z_{n-1})$.

3.5 prism

```
prism n dx dy dz x0 y0 z0 ...
```

Defines a prism which as the polygon with n vertices $(x_0\ y_0\ z_0)\dots$ as its basis and that extends towards the $(dx\ dy\ dz)$ vector.

If it has been declared beforehand (see **concave**), the polygon can be concave, but its edges should not cross themselves and there can be no double vertex (ie 2 vertices at exactly the same coordinates). Should this happen, the result is undefined.

3.6 sphere

```
sphere x0 y0 z0 radius [facets]
```

Draws a sphere centered on $(x_0\ y_0\ z_0)$ and with radius *diam*.

facets defines the number of facets used to approximate the sphere. The default value is 12.

3.7 ellipsoid

```
ellipsoid x0 y0 z0 dx dy dz [facets]
```

Draws an ellipsoid centered on $(x_0\ y_0\ z_0)$, with half-axis values $(dx\ dy\ dz)$, parallel to the global frame axes (a rotation is therefore required to draw an ellipsoid whose axes are not parallel to the global frame).

facets defines the number of facets used to approximate the ellipsoid. The default value is 12.

3.8 disk

`disk x_0 y_0 z_0 $axis$ $diam$ [$facets$]`

Defines a disk centered on (x_0, y_0, z_0) , whose normal is oriented towards one of the axis as specified in $axis$ (which can be **x**, **y** or **z** and whose diameter is $diam$).

$facets$ defines the number of facets used to approximate the disk. The default value is 12.

3.9 picture

`picture $image$ [$width$ $height$]`
`picture $image$ x_0 y_0 x_1 y_1 x_2 y_2 x_3 y_3`

Defines an image whose lower left corner will be in $(0,0)$ in the xOy plan from the Tk image called $image$. A $width$ (length along the x axis) and a $height$ (length along the y axis) can be optionnally defined.

The image can also be drawn into a non-rectangular shape by specifying the coordinate of the four corners explicitly.

This primitive should be used inside a display list for optimal performance. Otherwise it can be extremely unefficient.

3.10 drawString

`drawString [x y z] $string$`

Draws the string given as argument starting at the specified coordinates or at the current origin if no coordinates are given.

The string is drawn using the default OpenGL font.

3.11 repere

`repere [$length$]`

Draws a frame¹ centered on the current origin. The $length$ parameter defines the length of the drawn axis. The default value is 1.

¹*repère* in french

Chapter 4

The GDHE protocol

GDHE accepts display requests from the network. These requests are defined by a specific protocol, inherited from a previous version of GDHE, that was dedicated to the STRADA application, in the frame of the Martha project (and even another, much older version).

In the current version of GDHE the compatibility with this older version have been maintained. A request has been added to evaluate an arbitrary Tcl expression. This new request is sufficient for all applications that don't want to use the data types and representations from the Martha project.

The STRADA application is considering a multi-robots system in which robots are numbered from r_0 to r_{n-1} . Each robot is equipped with an orientable platform with one degree of freedom.

In this chapter, only the functions needed to use the current interface are described in details.

Gdhe and the client library support both IPv4 and IPv6 protocols. When a host has both v6 and v4 addresses, the IPv6 connection is tried first.

4.1 Requests

All requests and associated data structures are described in the `gdhe/GDHE_packet.h` header file.

The packet structure

This structure holds an union of all data types accepted by the GDHE requests, plus two fields *which* and *command* that indicate respectively which objects a given command applies to and what is the command sent by this request.

EvaExpression

The `evaExpression` request is used by a client of GDHE to make it evaluate an arbitrary Tcl expression. It is a basic generic request that allows to extend the functionalities of GDHE, by providing a mean to modify arbitrary parts of the model of the scene that is displayed.

Table 4.1: List of the main GDHE requests

Request	Parameter	Description
PLACE_ROBOT	position	places the <i>which</i> robot at the given position
ERASE_ROBOT	-	removes the <i>which</i> robot from the environment
PLACE_RS_TRAJ	rs_trajectory	Draw an Reed&Sheep trajectory in front of the <i>which</i> robot
ERASE_RS_TRAJ	-	removes the trajectory for robot <i>which</i>
EVAL_EXPRESSION	char *	evaluates a Tcl expression

4.2 Client library

Prototypes of the client library of GDHE are given in the `gdhe/GDHE_client_prot.h` file.

All these functions return TRUE is everything went OK or FALSE in case of an error.

4.2.1 Initialization

A client should start by creating a connection to the GDHE server. For this, it needs to know the name of the machine on which GDHE is running.

```
extern int get_connection ( char *server_name );
```

4.2.2 Termination

When a client exits, it gets disconnected automatically from the GDHE server. It can be useful to disconnect it explicitly, using the `disconnect` function.

```
extern int disconnect(void);
```

4.2.3 Evaluating a Tcl expression

The main function of interest in the GDHE client is this one, that sends an expression to be evaluated by the server, expressed as a C string (null terminated):

```
extern int eval_expression ( char *expr );
```

The result of the evaluation is not available to the client, since the interface is designed to be asynchronous, for performance reasons.

4.2.4 A simple example

The following sample program opens a connection to GDHE running on the local host and puts one robot at the origin;

```

#include <gdhe/GDHE.h>

int
main(int argc, char *argv[])
{
    get_connection("localhost");
    eval_expression("set pos(robot) { 0 0 0 }");
    eval_expression("set robots(sample) hilare2");
    exit(0);
}

```

To compile it use the following command (replace `${prefix}` by the actual path that you specified when installing GDHE):

```
cc -I${prefix}/include example.c -L${prefix}/lib -lGDHE
```

Or, using pkg-config:

```
cc `pkg-config --cflags gdhe` example.c `pkg-config --libs gdhe`
```

4.3 Access control

Since GDHE is a full Tcl command interpreter, the `eval_expression` function is a bit dangerous: any application that can get a connection to gdhe can use (almost) the full power of Tcl on this machine. Thus an access control mechanism have been implemented. By default, only the local machine is allowed to connect to GDHE.

Rules can be defined in the startup file, using the `allow` and `deny` operators.

```

allow regexp
deny regexp

```

regexp is a regular expression that can match either the host name or the numerical IPv4 or IPv6 address of the remote client that needs to be allowed or denied access.

All `allow` directives are evaluated first, followed by `deny` directives. Connections not matching an `allow` or `deny` rule are denied.

Example:

```

allow ^140\.93\.*
allow .*\.laas\.fr$

deny ^bad\.laas\.fr$

```

Allows all access from the `.laas.fr` domain, as well as all machine with IPv4 addresses in the 140.93/16 network. It denies access to one particular host `bad.laas.fr`.

By redefining the `clientAuthorize` Tcl procedure, it is possible to implement more sophisticated access control procedures.

Chapter 5

The Tcl-OpenGL interface

5.1 Introduction




Figure 5.1: Architecture of GDHE

GDHE uses the Tcl/Tk scripting language to program several elements of its user interface and to describe the scenes to be displayed.

The Tcl interpreter which is running asynchronously, is augmented by libraries of functions used to draw objects. These libraries are coded either in the C language or in Tcl itself. The interpreter is initialized by a configuration file that can be adapted for each application.

The Tcl interpreter acts as a server and can receive requests from its clients on a TCP/IP socket, or from the user who can send events through the graphical interface.

5.2 The display framework

GDHE offers a standard framework to display 3D data extracted either from a simulation or from real world data. By convention it uses a direct frame in which the Oz axis represents

the vertical.

Several parameters available in OpenGL are fixed in GDHE in order to simplify the task of describing of the objects to display.

Specifically, in the *model view* transform from OpenGL, the part corresponding to the position of the observer relatively to the scene is represented by a polar transformation where the coordinates of the target point, the distance, the elevation and the azimuth of the observer are specified.

Also, the rendering model is kept simple. GDHE does not offer all the rendering parameters from OpenGL that could be used to obtain a more sophisticated (and more realistic) rendering.

5.3 OpenGL primitives

GDHE extends Tcl with a set of functions that provide an access to OpenGL primitives.

5.3.1 Handling of 3D display windows

GDHE uses the *Togl* widget, developed by Brian Paul to interface OpenGL and Tcl/Tk.

togl

togl ident parameters...

Creates an OpenGL widget (a new window) identified by *ident*. The Tcl options recognized by **togl** are:

-width

-height specify the size of the window.

-ident associate an identifier with this widget. *Warning !* all widgets that use the same *ident* share the same observer position. By default this identifier is the empty string "".

-rgba specifies if the widget will use the RGBA mode

-double specifies if the widget will use a double-buffer

-depth specifies if the widget will use a depth buffer

-accum specifies if the widget will use an accumulation buffer

setObs

<i>widget</i> setObs	-dist	<i>dist</i>
	-elev	<i>elev</i>
	-azi	<i>azi</i>
	-x	<i>x</i>
	-y	<i>y</i>
	-z	<i>z</i>
	-fovy	<i>fovy</i>
	-perspective -ortho	
	-projMat	<i>matrix</i>
	-viewMat	<i>matrix</i>

Defines the position of the observer for the display window *widget*. The observer is looking at the (xyz) target point and its position is given in polar coordinates by the distance *dist* and the two angles of elevation *elev* and azimuth *azi*. *fovy* defines the horizontal field of view of the observer.

There are six global variables in Tcl that track the position of the observer, and automatically update it when modified: `obsDist`, `obsElev`, `obsAzi`, `obsX`, `obsY` and `obsZ`.

-perspective specifies that a perspective projection will be used to render the scene. (This is the default).

-ortho specifies that an orthogonal projection will be used to render the scene.

-projMat allows to specify explicitly the projection matrix, rather than having OpenGL compute it from the individual parameters.

-viewMat allows to specify explicitly the OpenGL view matrix.

redraw

widget redraw [*force*]

Triggers a redraw of the specified Togl *widget*. If the *force* parameter is omitted, the redraw will be done *as soon as possible*, when the Tcl interpreter becomes idle. If the *force* parameter is present and has a **True** value, the redraw is immediate, interrupting any other activity in the Tcl interpreter.

For optimal performance of GDHE, it is strongly recommended to avoid setting the *force* parameter.

dumpEps

widget dumpEps [*-color*] *file*

Creates an encapsulated PostScript file with the contents of the OpenGL window *widget*. If the *-color* option is present, the resulting PostScript file will use color, otherwise it will be in grey shades.

This function overwrites silently *file* if it already exists.

The **Dump EPS** button of the standard user interface is using this function.

dumpPpm

```
widget dumpPpm [-color] file
```

Creates an image file in the *PPM* or *PGM* format from the contents of the OpenGL *widget*. If the *-color* option is present, the resulting file will be full color (PPM format), otherwise it will use shades of grey (PGM format).

This function overwrites silently *file* if it already exists.

5.3.2 Frames

GDHE offers a simple interface with the functions to manage the stack of frames of OpenGL.

popMatrix

```
popMatrix
```

Pops the current transform from the top of the stack.

pushMatrix

```
pushMatrix
```

Pushes the current transform on the top of the stack.

rotate

```
rotate angle x y z
```

Defines a rotation of value *angle* around the axis oriented along the *(xyz)* directing vector.

translate

```
translate dx dy dz
```

Defines a translation.

loadIdentity

```
loadIdentity
```

Set the current transformation matrix to identity.

loadMatrix

```
loadMatrix m11...
```

Explicitly sets the current transformation matrix with the 16 values given as parameters.

getMVMMatrix

```
getMVMMatrix
```

Returns the current OpenGL ModelView matrix from current window.

multMatrix

```
multMatrix
```

5.3.3 Color

Currently, the only programmable attribute of surfaces displayed by GDHE is the color.

color

```
color red green blue [alpha]
```

Defines the current color. *Red*, *green* and *blue* are integers between 0 and 255. **color** defines both the ambient color and the diffuse reflexion color of the objects. The optional parameter *alpha* specifies the α channel value of the color. It is not really currently used by GDHE. (Some preliminary support for transparencies exists, but it's not really functional yet).

clearColor

```
clearColor red green blue [alpha]
```

Defines the background color of the image. *Red*, *green*, *blue* and *alpha* are integers between 0 and 255.

5.3.4 Other random procedures

concave

```
concave option
```

Indicates to prism- (prism §3.5) and polygon- (polygon §3.3) drawing primitives if the following objects are concave. If *option* is **True**, then objects can be concave and the tessellation function of the GLU library will be used to decompose the polygons into triangles before displaying them. If *option* is **False** the polygons are supposed to be convex and can thus be rendered directly.

If **concave false** was asserted and a concave object is evaluated, the displayed result is not predictable (and will generally look ugly).

cullFace

cullFace *option*

Defines if OpenGL should remove the back faces from the objects. If *option* is **True**, then back faces (oriented in the negative direction) are not displayed. If *option* is **False**, then back faces are displayed.

setLights

setLights

Re-reads the values of the Tcl variables that define the lighting of the scene. See § 5.4.2.

sleep

sleep *milliseconds*

Suspends the execution for the specified number of *milliseconds*. Don't use this command for too long pauses, because the application is totally unresponsive during this pause.

5.3.5 Display lists

The functions described here provide an interface with the primitives to manipulate *display lists* in OpenGL. They can be either used directly or through the more sophisticated **object** interface (see §2.2.1) to declare and display complicated shapes in one operation.

newList

newList *n*

Starts a new display list definition, numbered *n*. If there was already a display list with this number, it will be lost and replaced by the newly created one.

Please note that GDHE renders display lists while creating them (meaning that the OpenGL GL_COMPILE_AND_EXECUTE parameter is set).

endList

endList

Ends the definition of a display list.

callList

`callList n`

Displays the specified display list.

genLists

`genLists n`

Provides a mechanism to allocate unique display lists numbers. *n* specifies how many indexes should be allocated. `genLists` returns the first allocated index. If *n* indexes were requested, the *n* - 1 other are following in sequence.

deleteLists

`deleteLists index [n]`

Frees the *n* display lists starting at *index*. If *n* is omitted, it defaults to 1.

5.4 Tcl procedures and variables

GDHE can be programmed with the Tcl language. Every GDHE application has to provide two specific Tcl procedures that are called by GDHE to perform its initialization and the drawings.

When GDHE starts, the `${GDHE}/tcl/setup.tcl` file is read by the Tcl interpreter. This file is part of the standard GDHE application and should generally not be modified in the normal use of the standard GDHE application.

In order to customize the standard GDHE application, the `.gdherc` file can be used. This file is read after `setup.tcl`, so that everything defined there can be overridden by `.gdherc`.

The `setup.tcl` file defines procedures and variables that are used afterwards by GDHE to manage the display. This section describes those procedures and variables.

5.4.1 Procedures called by Tcl

setup

`setup`

This Tcl procedure is called without parameters during GDHE startup, after reading the configuration file (`.gdherc`). The aim of this procedure is to set up the GDHE graphical user interface (create one or more OpenGL widgets and the associated control panels).

The standard GDHE application comes with a default `setup` procedure that opens one OpenGL window and the default control panel described at § 2.1.1. This behaviour can be altered by several global variables, `gdheBase`, `gdheNoControlPanel`, `gdheToglWidth` and `gdheToglHeight`. These variables can be set in `.gdherc`.

`gdheBase` is the name of a Tk widget that will be the father of the main OpenGL window (defaults to “.”). In order to encapsulate GDHE in a pre-existing Tk application, just set `gdheBase` to the name of an existing Tk frame.

`gdheNoControlPanel`, if defined, prevents the creation of the standard control panel.

`gdheToglWidth` and `gdheToglHeight` define the size of the togl widget created by GDHE (the default size is 640×480).

draw_all

`draw_all widget`

This Tcl procedure is called each time GDHE needs to redraw the contents of an OpenGL widget, either after the windowing system sent a redraw event or after an explicit call to the `redraw` procedure. It gets the name of the widget to redraw as an argument.

5.4.2 Variables used by GDHE

Initialization

Gdhe reads the init script defined by `tclRcFileName` in the Tcl interpreter. After loading `setup.tcl` and executing the `setup` procedure, it evaluates the contents of the `gdhe_after_setup_rc` variable, if it exists.

The size of the world used by GDHE is defined by the `xmin`, `xmax`, `ymin`, `ymax`, `zmin` and `zmax` variables. If these are defined in the startup script or before loading the GDHE module, the environment will have the size specified by these variables, otherwise a default size is used.

The `env_size` procedure can be used to alter the size of the world after GDHE initialization. Calling this procedure may break some functionalities that rely on the values of the above variables being constant during one session, but is generally safe in simple static environments.

`env_size widget xmin ymin zmin xmax ymax zmax`

Automatic redraw

By default GDHE redraws the contents of the OpenGL window automatically after receiving and handling each request of a client. This automatic redrawing is controlled by the `auto_redisplay` variable which has the default value of 1.

If a client application needs to send several requests without triggering a redraw, it can set this variable to 0 and then explicitly call `redraw` for a specific window, or `redrawAllWindows` for all GDHE windows.

Lighting

GDHE uses Tcl variables to specify the lighting parameters of the scene. Since OpenGL can handle up to eight light sources, these variables are arrays in the Tcl namespace `Gdhe::lights`, whose indexes are **LIGHT0** to **LIGHT7**.

Gdhe::lights::position defines the position of the light sources. Each element of the array is a list of three or four elements that define the $(x\ y\ z)$ coordinates or the direction of the source.

If the list is composed of three elements or if the fourth element is equal to 0, then the light source is placed at the infinity and the three first elements define the direction of the source in the GDHE main frame. In this frame, $(0\ 0\ 1)$ is a light source placed vertically above the scene.

If the fourth element is not 0, the source is placed at the point with coordinates $(x\ y\ z)$.

Gdhe::lights::ambient defines the color and intensity of the ambient component of each light source.

Gdhe::lights::diffuse defines the color and intensity of the diffuse component (reflected by the objects) of each light source.

Gdhe::lights::enabled allows to enable or disable each of the eight sources individually. Each value is interpreted as a boolean.

Chapter 6

Extension modules

GDHE can be extended using Tcl modules that will provide new objects types or new procedures.

The procedure to load a GDHE extension is the same as for any Tcl module. Place:

```
package require module_name
```

in the GDHE init file `.gdherc` before using the procedures and variables it defines.

This chapter describes the existing extension modules.

6.1 Numerical Terrain Models

The terrain module allows to display numerical terrain models.

6.1.1 readTerrain

```
readTerrain name filename
```

Reads a terrain model in the file format used by LAAS EDEN experiments stored in the file specified by *filename* and creates a terrain with name *name* in GDHE's memory.

The color of each terrain vertex is obtained from the type associated in the data with this vertice, used as an index in the `mntColor` Tcl array.

6.1.2 readTerrainGeroms

```
readTerrainGeroms name filename
```

Same as `readTerrain`, except that the expected format of the terrain model is the one produced by the GEROMS tools.

6.1.3 terrain

```
terrain name
```

Draw the named terrain in the current scene. If no terrain with the given name exists, an error is generated.

6.1.4 deleteTerrain

```
deleteTerrain name
```

Destroys the terrain model named by *name* and frees the associated memory resources.

6.1.5 infoTerrain

```
infoTerrain name x0|y0|z0|dx|dy|dz
```

Returns information about the given terrain. One parameter should be specified to tell which information should be returned.

6.1.6 Terrains types

The `mntColor` array defines colors associated with each terrain type. Since the interpretation of the possible terrain types values is leaved free to the user, it's also the user's role to associate appropriate colors with the various possible values for each vertice's type.

Each element of this array should be an a triple $\{ r \ g \ b \}$ where eqch component between 0 and 255 corresponds to the red, green and blue components respectively.

6.2 Planet

The `planet` module allows to draw a sphere representing a planet : a picture of the surface is projected as a texture on the outer surface of the sphere.

6.2.1 initPlanet

```
widget InitPlanet [-interior] [-radius radius] [filename]
```

Computes in the specified OpenGL widget an object representing a planet, using the picture stored in *filename*, or a default picture of the earth if *filename* is not specified. The **BUILTIN** string can be used to refer to this image.

GDHE provide some texture files in the `${GDHE}/images` directory:

<code>earth.xbm</code>	simple monochrom model of the earth
<code>earth.xpm</code>	a colorful view of the earth from satellite images
<code>earthcld.xpm</code>	clouds from the high atmosphere of the earth

The `-interior` parameter indicates to OpenGL that the inner face of the sphere is to used instead of the outer one. This is allows to create cloudy skys effects.

The `-radius` parameter specifies the radius of the sphere. The default is to create a sphere of 10m of radius.

Since this function only defines the display list for on OpenGL widget, it should normally never be called directly. Use the Tcl `planet` procedure instead.

6.2.2 drawPlanet

`drawPlanet`

Draws the current planet in the current OpenGL window at position (0 0 0).

This function should normally not be called directly. Use the `planet` procedure instead, or build you own procedure using `planet` as a model.

6.2.3 planet

`planet name filename`

This procedure draws a planet. It is suitable as a value in the `robots` array. *name* gives a name to the object and *file* defines the name of the file containing the image to be used as a texture.

Example:

```
set robots(earth) { planet earth $env(GDHE)/images/earth.xpm }  
set pos(earth) { 0 0 0 }
```

6.2.4 Bugs

- There is a problem when handling multiple windows
- This should be standardized with other similar GDHE modules

6.3 Tkjpeg

The `tkjpeg` module is a general Tk module that provides support for JPEG format images to the Tk Photo widget. This module can also be used outside of GDHE. It was developed by the GDHE author in order to be able to display images in JPEG format obtained from an HTTP server using the Tcl http client code in GDHE.

`jpegread photo channel`

Is an additional procedure provided by this module; it reads a JPEG image from the given Tcl *channel* into the existing Tk *photo* widget, bypassing some of the additional tests done by the Tk photo callbacks.

Bibliography

- [1] R. Alami, S. Fleury, M. Herrb, F. Ingrand, and F. Robert. Multi robot cooperation in the martha project. *IEEE Robotics and Automation Magazine*, 1997.
- [2] J. Nieder, T. Davis, and M. Woo. *OpenGL Programming Guide, The Official Guide to Learning OpenGL, Release 1*. Addison Wesley, 1993.
- [3] J. K. Ousterhout. *Tcl and the Tk Toolkit*. Addison-Wesley, 1994.
- [4] B. Welch. *Practical Programming in Tcl and Tk*. Prentice Hal, 1996.

Index

A		EPS dump	8
allow	19	eval_expression	18
arm	12	F	
auto_redisplay	27	fill	8
azimuth	8	G	
B		Gdhe::lights	27
B21r	12	Gdhe::lights::ambient	28
box	14	Gdhe::lights::diffuse	28
BUILTIN	30	Gdhe::lights::enabled	28
C		Gdhe::lights::position	28
callList	26	gdhe_after_setup_rc	5, 27
clearColor	24	gdheBase	26
clientAuthorize	19	gdheNoControlPanel	26
color	24	gdheToglHeight	26
concave	24	gdheToglWidth	26
cullFace	25	genLists	26
cylinder	14	get_connection	18
D		getMVMatrix	24
deleteLists	26	H	
deleteTerrain	30	h2	12
deny	19	h2_platform	12
desk	10	h2bis	12
disconnect	18	I	
disk	16	infoTerrain	30
display lists	25	InitPlanet	30
distance	8	J	
draw_all	27	jpegread	31
drawPlanet	31	junior	12
drawString	16	junior_platform	12
dumpEps	22	L	
dumpPpm	23	lama	12
E		lama_platine	12
elevation	8	LIGHT0	27
ellipsoid	15	LIGHT7	27
endList	25	lights	8
env_size	27		

line	8	rotate	23
loadIdentity	23	rs_trajectory	9
loadMatrix	24		
M		S	
mntColor	29, 30	scout	12
Models	11	setLights	25
multMatrix	24	setObs	22
N		setup	26
newList	25	sleep	25
O		sphere	15
object	9	T	
obsAzi	22	target point	8
obsDist	22	tcl_rcFileName	27
obsElev	22	terrain	29
obsX	22	tkjpeg	31
obsY	22	Togl	21
obsZ	22	togl	21
orthogonal	8	translate	23
P		X	
perspective	8	xmax	27
PGM	23	xmin	27
picture	16	xr4000	12
planet	30, 31	Y	
platform	9	ymax	27
polygon	14	ymin	27
polyline	15	Z	
popMatrix	23	zmax	27
pos	9	zmin	27
PostScript	8		
PPM	23		
prism	15		
pushMatrix	23		
Q			
quit	8		
R			
rackham	12		
readTerrain	29		
readTerrainGeroms	29		
redraw	22		
redrawAllWindows	11		
reper	16		
robots	9		